Godrej

seeTHRU 7
PRO
VIDEO DOOR PHONE

USER MANUAL

WARNING AND CAUTION

Please make sure to follow the instructions to prevent any danger or property losses.

⚠	**Warning: Death or serious injury are expected.**
🚫🔧	Do not disassemble, install, or repair this product on your own accord.
🚫	Do not place the product near a hot or humid place.
	Do not forcibly bend the cord or put a heavy object on the product.
	Do not use water, thinner or a detergent used to wash oil products when you wash the exterior.
	Do not connect to other products while in use.
❗	Make sure to clean it by using a dry cloth to prevent any breakdown or electric shock.
	If the product emits a peculiar noise, odor or smoke, immediately cut off the power, and then contact the service center.
🚫✋	Do not put the plug in the socket with a wet hand.

⚠	**Caution: An injury or property losses are expected**
❗	Make sure that dust or foreign substances are not gathered on the product.
	Make sure to prevent foreign substances from entering the product.
	Avoid direct rays of the sun or heating devices at a time of installation.
	Install the product in a flat and stable place.
🔌	Pull the plug if the product is not used for a long time.
🚫	Do not unplug the micro SD card when recording, this generally will cause loss of data.

1. FEATURES AND FUNCTIONS

· 7" Color indoor monitor with touch button
· Support 2 door stations
· Brightness, color and contrast adjustable
· Ringtone volume adjustable
· Hands-free
· Support DC 12V power input
· Wide angle color camera
· Inbuilt memory to Store upto 60 images.
· Support intercom network(Non addressable)
· Support 2 CCTV Input
· OSD menu
· Door lock release
· Monitoring and talking with a visitor
· Inbuilt WIFI
· Provision to monitor and talk with visitor over mobile.

2. SPECIFICATIONS MONITOR UNIT

| Category	Specification
TFT LCD	7 inch digital TFT LCD
LCD resolution	800(RGB)*480
Connection with camera	Support two 4wire outdoor stations and 2wire CCTV
Input power	DC:12V/2A
Power consumption	Max:7W Standby:1.5W
Dimensions(mm)	204(W)×130(H)×16(D)

3. SPECIFICATIONS OUTDOOR PANEL

| Category	Specification
Camera Resolution	700 TVL
Night vision	White LED
Wiring	4 Wire Monitor/2 Wire Electronic lock
Operation temperature	205(W)×128(H)×18(D)
Dimension (mm)	124(H)×40(W)×25(D)

4. VDP (VIDEO DOOR PHONE) CONTENT


Out Door Panel



Indoor Monitor

Power Adapter

User Manual

KA 4x35mm
Mounting Screw


M 4x35 mm
Plastic Expansion Pipe

2 Pin Power
Cable x 3

4 Pin Power
Cable x 6

Angular Bracket

5. KNOW YOUR PRODUCT

No.	Part Name	Description
1	Memory Button	Monitoring interface used for menu selection
2	Intercom Button	Intercom Button between indoor monitors
3	Monitor Button	Button for monitoring outdoor panel
4	Talk Button	Button for talking with visitor
5	Unlock Button	Button for unlocking the door
6	MIC	Microphone
7	Power Indicator	Power LED light

No.	Part Name	Description
2	CCTV Input	Interface for CCTV1 Input
3	CCTV Input	Interface for CCTV2 Input
4	DC Out	Interface for DC power supply
5	Video Input	Interface for CAM2
6	Intercom	Interface for intercom
7	DC In	Interface for DC power supply
8	Video Input	Interface for CAM1
9	Intercom	Interface for intercom

No.	Part Name	Description
1	LED Light	For night vision
2	Camera	Wide angle high quality camera
3	Speaker	To get the audio from Indoor monitor
4	Call Button	To ring call in indoor monitor
5	Microphone	To send audio to Indoor monitor
6	Terminal for Electronic Lock	To connect electronic lock
7	Terminal for Indoor Monitor	To connect indoor monitor with outdoor panel

6. OPERATION OF THE VIDEO DOOR PHONE

- Visitor press the call button of the outdoor panel to call the monitor.

- To accept the call, press Talk button on the video monitor.

- Talking time lasts for 60s.

- To talk between the monitor and camera unit, please press

- To Intercom with the slave monitor, please press

- To Monitor the outdoor panel, please press

- To control an electric door release, please press

Setting Page

Press the last button get into setting page

- In **[Time]** setting page, you can set the date&time of the monitor and select the date format
- In **[Mute]** setting page, you can enable/disable the mute function and set the time range for mute mode
- In **[Memory]** setting page, you can delete all images in FLASH
- In **[Melody]** setting page, you can set the ring melody for CAM / Intercom and set ring time
- In **[Setting]** setting page, you can turn on/off touch beep, factory reset device and check UID & SSID in Wi-Fi setting page

Remark: To add a new device in APP, Use Godrej Seethru Pro+ app and scan the UID QR code provided in Wi-Fi section

Time Setting

In 🕐 you can adjust year/month/day/hour/minute.

In 📅 you can set the format of date.

In 🔇 you can enable or disable the mute mode.

In ⏱▶ set the start time of mute mode.

In ⏱■ set the end time of mute mode.

Remark: 🔇 means the mute mode is turned on, 🔊 means the mute mode is turned off.

Storage Setting

In 🗑 you can delete all images in flash.

Ring Setting

In 🎵1 you can choose the ring melody for door1 and door2.There are 6 melodies for selecting.

In 🎵 set the ring duration between 10 seconds and 30 seconds.

Other Setting

In ⏽ you can enable or disable the touch beep.

In 🔄 you can factory reset the device.

In 📶 you can check the UID and reset the WIFI.

Wi-Fi Setting

SSID :
UID :   TTkscksgebuy

Long press 🔄 to reset the WIFI setting.

Talk Function

When talking with outdoor unit, long press ▶‖ to change the 📶🔔 ringing sound,

📶💬 talking sound, ⦙⦙⦙ brightness and 🎨 saturation.

Press 👤 to change channel from,the order is door 1,door 2,CCTV1,CCTV2

Press 📞 to hang up the call.

7. INSTALLATION

INDOOR MONITOR

OUTDOOR PANEL

•Choose a suitable location to install the system, it is recommended to fix the monitor at the user-eyes height between 145cm and 160cm.
•Mark the holes of the frame on the wall and drill the holes.
•Drill the hole into the wall in the center of the bracket for cables go through the wall.
•Fix the bracket with extension pipe and screws.
•The outdoor panel should be mount at eye level of a person.

8. CABLING REQUIREMENT

Video door phone system uses 4 core cables. Cable should be used according to different distance requirement from outdoor panel to indoor monitor. In the areas with high possibility of interference it is recommended to use a 75 ohm coaxial for connection for better video signal.

RVV4 (mm)	0.3	0.5
Distance (mm)	30	50

Note: For long distance installation it is recommended to use good quality 3+1 cable.

9. PRECAUTIONS

•Do not place the monitor into environment with high temperature and damp places.
•Protect the lens of outdoor camera unit from direct sun light to avoid pale picture on the monitor.
•Do not use the equipment when with vibrations environment. Protect the equipment from falls.

Note: The outdoor unit is suitable to install only inside the building. Do not install it in open area. Other wise There is risk of damage to product.

10. INFORMATION ON E-WASTE HANDLING AND MANAGEMENT

Dear Customer,

The Ministry of Environment and Forests have published The E-waste (Management and Handling) Rules 2010 which comes in e ect from 1st May 2012.

E-waste is defined as any electrical or electronic component of products in whole or in part, or rejects from their manufacturing or repair process which are intended to be discarded.

These rules apply to every producer; consumer or bulk consumer involved in the manufacture, sale, and purchase and processing of electrical and electronic equipment or components as specified in Schedule 1 (please refer to our website www.godrej.com under the `Green Think' sec of Godrej Security Solutions Division Page for more details).

Under these rules, specific roles and responsibilities are defined for producers, consumers and recycles handling and managing e-waste.

E-waste is to be managed in an environmentally sound manner which means, taking steps to ensure that health and environment are protected from adverse e ects of hazardous substance contained in such wastes.

Rule 6 of the E-waste (Management and Handling) Rules 2010 states that bulk consumers of electrical and electronic equipment shall be responsible for recycling of the e-waste generated by them. Bulk consumer means bulk users of electronic and electrical equipment such as Central Government or State Government Departments, public sector undertakings, banks, educational institutions, multinational organisations, and international agencies, private companies that are registered under the Factories Act, 1948 and Companies Act, 1956. The bulk consumers have to ensure that the e-waste generated by them is channelised to authorised collection centres or is taken back by the producers. They shall maintain records of e-waste generated by them in Form 2 and make such records available for scrutiny by the State Pollution Control or the Pollution Control Commitee concerned.

All consumers of electrical and electronic equipment irrespective of their status as bulk consumers or not, shall ensure that e-waste generated by them is channelized to authorized collection centres (s) or registered dismantler(s), or recycler(s) or is returned to the pick¬up/take back services provided by the producers. (Please refer to our website www.godrej.com under the `Green Think' sec of Godrej Security Solutions Division Page for more details).

All our products intended to be recycled under the category of e-waste (as defined above) carry a label or stamp of the WEEE symbol (A wheelie bin with a cross), which states that it falls under the hazardous waste category and is not to be disposed of along with normal garbage.

We seek your support in ensuring environmentally sound management of e-waste and aid us in sustaining our earth's natural resources and maintaining the earth's green cover intact for the benefit of our future generations.

RECORD OF PURCHASE

Please fill your details below for future reference.

Date of purchase: _____

Product model: _____

Name & address of Distributor/Dealer: _____

_____

_____

Distributor phone number: _____

FOR SAFETY, PLEASE READ THIS MANUAL PRIOR TO USE.